







The skirt is attached to the bathtub by clamps at the top and support screws at the bottom. To remove it, first remove the screws with the white caps at the bottom and then loosen the clamps on the side. To install it, first place the skirt onto the clamps and tighten them, then insert the bottom screws and put the caps.

